

## How to Reset range extender?

### Step1

Enter range extender rest mode:

Hold left Throttle up right (see photo), right throttle up left.



### Step2

Turn on remote power



### Step3:

Release the left & right throttle, in remote controller, now you will see the X (drone) sign blink in red & green color. Once you see the range extender sign turn in red (Green), please press home button down, now the range extender is in reset mode.



### Step 4:

Then the range extender(wifi) sign show yellow color. Once you see the range extender sign turn in red, please press home button up, and turn off/and on remote.

Now range extender name/password reset, reset success.

